



CONCURE

670 Crack Fill Binder

INSTALLATION INSTRUCTIONS

Product Description: The 670 Crack Fill Binder is a premixed white liquid, which combines a specialized Acrylic Co-Polymer and a high strength self-leveling cement.

Basic Use: When mixed with a high strength self-leveling cement, the crack fill binder enables all saw cuts, cracks and construction joints to become impermeable, so that no moisture can intrude through these voids. So the LIFETIME warranty applies to these critical areas, the Crack Fill Binder is mandatory with the use of all Concure Systems Moisture Control Systems.

Coverage: 150 lineal feet per pail

INSTALLATION INSTRUCTIONS:

- Using a 4" grinder and a "V" Crack Chase Blade, "V" out the top of all saw cuts, construction and cold joints, and large cracks. Rule of Thumb: if a dime can fit, v-groove, clean and fill.
- Scrape, Vacuum all joints
- Using a small paint brush, brush a thin coat of the crack fill Acrylic Co-Polymer liquid into the joint, along the side walls and bottom of the joint, make sure all areas are coated
- Following the mixing instructions on the bucket, mixing enough material only to fill what has been primed
- Pour mixed product into a grout bag and fill joints/cracks so the crack fill binder is above grade, making sure the space is full with no voids or air pockets
- Wait 30-60 minutes using a putty knife or 4" scraper, scave off excess materials
- Let dry thoroughly before skim-coating with cementitious material
- Following manufacturer specifications finish patching the joints using a good grade Portland based floor patch

Step by Step Instructions on Next Page



CONCURE

670 Crack Fill Binder

INSTALLATION INSTRUCTIONS

Steps for applying 670 Crack Fill Binder:

1) When using the 670 crack fill binder the first step is to groove the walls off the saw cut joint or cracks etc



2) Using a small paint brush apply a coating of the 670 Acrylic primer along the walls and bottom of joints



3) After mixing 670 to flowing consistency, use a mortar bag to dispense into cracks

